

SIRUBA

電控參數說明書

ELECTRONIC CONTROL PARAMETER MANUAL

■ F006KQ-UTN



绷缝机一体机自动剪线使用说明书

User manual of F006KQ-UTN All-in one Auto-Trimmer servo Motor

前言

Foreword

欢迎使用本公司产品，制衣行的正确投资选择！

Welcome to use our products, it is the right investment choices in garment industry!

本说明书为本公司新研发的“绷缝机自动剪线”产品做对照参考手册，请认真阅读此手册以便更好的运用本公司产品！

The User manual is for our newly developed F006KQ-UTN Auto-Trimmer servo Motor system " products Reference Manual, Please read this manual carefully, hope it can give you useful help.



阅读本说明前以下要求说明请注意

Before reading the manual, Please note the following requirements

- 1、用户使用作业前必须可靠接地，保证人身安全！

The user must be grounded before operations to ensure safety

- 2、非专业人士请勿拆卸控制箱

non-professionals do not disassemble the control box

- 3、控制箱与电机远离强磁高辐射环境

The control box and motor away from the magnetic high radiation environment

- 4、不要在过热环境中作业

Do not work in hot environments

- 5、不要在过于潮湿环境中作业

Do not work in humid environments too

- 6、用户保证供电电压的稳定（210V~240V）

Users to ensure stable supply voltage (210V ~ 240V)

安全叮嘱：Safety requirement

- 1、电机接通时请不要把脚放在脚踏板上

Do not put your feet on the pedals when the motor is switched on

- 2、本产品请专业人士安装调试

Let professionals to install and debug this product

- 3、严禁在通电时打开控制箱与电机端盖

Do not open the control box and the motor cover when energized

- 4、换针，穿线或更换底线时请关闭电源

Please turn off the power when changing the needle, threading or replacing the bottom line

- 5、安装，拆卸维修时请关闭电源

During installation and removal service, please turn off the power

- 6、翻抬缝纫机时请关闭电源

Please turn off the power when turn lift sewing machine

保修策略：Warranty Policy

- 1、本产品自购买起免费保修 2 年，终身维护。保修期内除人为损坏外出现任何质量问题可免费修

Since from the purchase of this product, we give 2-year warranty for free, Lifetime Maintenance. during the warranty period ,Any quality problems the product will be free repaired, Except artificial damage.

- 2、未经本公司同意自行拆卸，改装造成损坏将不给予保修。

without our consent disassemble or modify, the damaged will not give in warranty

- 3、但凡出现无法解决的问题可以联系本公司

Whenever find the problem can not be solved, you can contact the company

目录

Contents

电控介绍

Servo System Introduction

一：显示屏常用操作介绍

Introduction of display screen common Operation

二：如何进入参数与如何修改参数

How to enter parameters and how to modify the parameters

三：操作参数说明表

Operating Parameter Description Table

四：控制箱端口说明

The control box Port Description


五：错误代码解析

Error code analysis

一：显示屏常用操作介绍

Introduction of display screen common Operation

1、显示屏介绍如下：The display screen is described as follows




2.功能介绍：Function introduction



序 号 Serial No.	按键图标 Button Icons	功 能 说 明 Function Description	快捷说明 Quick description
1		中途抬压脚与半后踏抬压脚功能键 ※：功能开启时按键将亮起，屏幕显示半后踏抬压脚：开；功能关闭时按键将变暗，屏幕显示半后踏抬压脚：关 Middle foot lifter and half-back step foot lifter function key	长按进入压脚功能模块 Long press enter into Auto-foot lifter Function modules

		※: the key lights on when the function is on, the screen shows half-back step foot lifter function is on, the key lights off when the function is off, the screen shows half-back step foot lifter function is off	
2		剪线自动抬压脚模式（剪线后自动抬起压脚） ※: 功能开启时按键将会亮起，功能关闭时按键将会变暗。 Auto- trimmer and auto-foot lifter function(after auto-trimmer, the foot lifter automatically) ※: when the function is open, the key lights on; when the function off, the key lights off	
3		剪刀功能开启和关闭键 ※: 功能开启时按键将亮起，功能关闭时按键将变暗，功能关闭时扫线功能关闭 Auto-trimmer function On or Off key ※: when the function is open, the key is on; when function off, the key is off, the function of pulling out the thread will be off when the trimmer function is off	长按进入剪刀功能模块 Long press enter into Auto-trimmer Function modules
4		按P 键同时按+，进入用户参数。 按P 键同时按-，输入密码，进入系统参数。 Press P and +, enter the user parameters. Press P and -, enter the system parameters with password.	
5		机头 LED 灯开关键 ※: 亮度 0-5, 0 表示机头 LED 关闭，此时按键变暗，1-5 档时机头 LED 开启，按键变亮 Machine head LED light On or Off key ※: luminance value 0-5, 0 means the LED light off, the key will be off. 1-5 means the LED light on, the key will be on	
6		慢启动功能键 ※: 开启后按键将亮起，关闭时按键将变暗。 Slow start function key ※: when the function is on, the key will light on, when the function off, the key will light off.	
7		上下停针位切换键，相应功能将可视化 ※: 屏幕显示停车针位: 上停针，表示上停针功能开启; 屏幕显示停车针位: 下停针，表示下停针功能开启; Up or down needle position transfer key, the related function will be Visualization ※: the display screen shows needle stop position: upper needle position, means the upper needle stop position is open; the display screen shows needle stop position: down needle position, means the down needle stop position is open	
8		自由缝纫模式 ※: 开启后按键将亮起，  将变暗，多段缝模式关闭 Free sewing mode When open, the key will be light on, the  will be light off, the multi-part sewing mode off	

9		参数确定保存键 Parameter determines the Save button	长按 OK 锁屏 Long press to lock the screen
10		多段缝模式键 ※：开启后按键将亮起，  将变暗，自由缝模式关闭 Multi-part sewing mode key ※： the key will light on when open the function, the  will be light off, the free sewing mode off	长按进入多段缝设置，可调节段数和每段针数 Long press to enter the setting of multi-part sewing, to adjust the prats number and the needle number
11		恢复出厂设置键 恢复出厂设置（需长按进入并输入密码） Return to factory setting key Press to enter: return to factory setting(need long press the key and enter the password)	
12		“+” 键（修改参数时加），处于主界面时按一下加 50 速度 “+” button (modify the parameters plus), increase 50RPM when pressing the key for once time on the host interface	
13		“-” 键（修改参数时减），处于主界面时按一下减 50 速度 “-” button (modify the parameters minus), decrease 50RPM when pressing the key for once time on the host interface	
14		向左键（在进入参数项时光标向左移） Left key (when adjusting items)	
15		向右键（在进入参数项时光标向右移） Left key (when adjusting items)	

二、如何进入参数与如何修改参数

How to enter parameters and how to modify the parameters

系统参数进入解析：

- 1.按 () 键同时按 () 键，进入用户参数，选择需调整的参数，用 () () 键调整参数值，按 () 键确认。
- 2..按 () 键同时按 () 键，输入密码 2014 进入系统参数，选择需调整的参数，用 () () 键调整参数值，按 () 键确认。

3.修改完毕参数后按（）键退回上一个页面，按（）键进入下一个页面。

注： 以上是进入方法，具体参数号代表的参数意思详情如下 “3.操作参数说明表”

System parameters entering analysis:

1. Press （） and （） key to enter the user parameter, select the parameter and adjust the value with （） and （） key, confirm with （） key.
2. Press （） and （） key to enter the system parameter with password 2014, select the parameter and adjust the value with （） and （） key, confirm with （） key.
3. After modifying the parameter value, press （） key to return back to the previous interface, press （） key to enter next interface.

Note: the upper is entry method, specific parameters No. on behalf of the parameters meaning as follows: “三： Operating Parameter Description Table”

三： 操作参数说明表： Operating Parameter Description Table

系统参数列表： System parameter list

菜单号 System parameter list	功能说明 Function Description	功能参数默认值 Function parameter default values	功能参数范围 Function parameter ranges	参数说明 Parameter Description
P1	最大缝纫速度 MAX Sewing speed	3800	200 ~ 6500	转 / 分钟 Round / Minute
P2	起缝速度 Start sewing speed	200	150 ~ 800	转 / 分钟 Round / Minute
P3	踏板加速曲线 Pedal acceleration curve	85	10 —100 %	
P11	慢启动选择 Slow Start Selection	0	0 — 1	0: 禁用 1: 启用 0: Disable 1: Enabled
P12	慢启动针数	2	1 — 30	针数


	Slow start Stitches number			Stitch number
P13	慢启动速度 Slow start speed	350	200 — 800	转 / 分钟 Round / Minute
P22	电机驱动方向 Motor drive orientation	1	0 — 1	0: 逆时针 1: 顺时针 0: Counterclockwise 1: Clockwise
P23	显示当前速度 Displays the current speed	0		显示当前的电机转速 Displays the current motor speed
P24	显示调速器电压 Display foot controller voltage	0		显示调速器输出电压 Display foot controller output voltage
P25	自动磨合运行 Automatic running-in operation	0	0 — 1	0: 关闭 1: 启动 0: OFF 1: ON
P34	上停针角度 The angle of upper needle stop position	0		
P35	下停针角度 The angle of down needle stop position	180		
P36	剪刀动作延时启动时间 Delayed start time for knife action	005	0 — 2000	毫秒 Millisecond
P37	剪刀动作时间（全功率+维 持功率） Knife action time (full power + maintain power)	110	10 — 2000	毫秒 Millisecond
P38	剪刀动作全功率时间 Full power scissors action time	260	10 — 990	毫秒 Millisecond
P40	剪刀动作维持功率调整 maintain power adjustment for knife action	50	1 — 100	百分比 Percentage
P41	剪刀动作释放保护时间 Knife action release the protection time	35	20 — 800	毫秒 Millisecond
P43	剪刀动作复位开关使能 Scissors action reset switch enable	1	0 — 1	0: 禁用 1: 启用 0: Disable 1: Enabled
p44	下剪刀手动动作模式	1	0-1	0: 禁用（缝制过程中结束或者用 手转动机器后，后踏不剪线） 1: 启用（缝制过程中结束或者用手转 动机器后，后踏可以剪线） 0: Disable 1: Enabled
P46	拨线动作延时启动时间 Wiper action delayed start time	40	0 — 2000	毫秒 Millisecond
P47	拨线动作时间（全功率+维 持功率）	70	10 — 2000	毫秒 Millisecond

	Wiper action time (full power + maintain power)			
P48	拨线动作全功率时间 Wiper action time at full power time	35	10 — 990	毫秒 Millisecond
P50	拨线动作维持功率调整 Wiper action time at maintain power adjustment	50	1 — 100	百分比 Percentage
P51	拨线动作释放保护时间 Wiper action release the protection time	50	20 — 800	毫秒 Millisecond
P55	吹气模式 Blow mode	000	0-4	0: 普通扫线 normal Sweep thread 1: 剪一次吹一次 cut one time blow one time 2: 每次抬压脚都吹 Blow for each foot lifter 3: 长吹 Long blowing 4: 断吹 break blow
P56	压脚动作延时启动时间 Foot-lifter action delayed start time	110	0 — 2000	毫秒 Millisecond
P57	压脚动作时间（全功率+维持功率） Foot-lifter action time (full power + maintain power)	260	100 — 2000	毫秒 Millisecond
P58	压脚动作全功率时间 Foot-lifter action time at full power time	160	10 — 990	毫秒 Millisecond
P60	压脚动作维持功率调整 Foot-lifter action time at maintain power adjustment	20	1 — 90	百分比 Percentage
P61	压脚动作释放保护时间 Foot-lifter action release the protection time	80	20 — 800	毫秒 Millisecond
P62	压脚抬起后自动放下时间 Automatic presser foot lifter down time	10	1 — 120	秒 Second
P65	半后踏抬压脚延时启动时间 Half-back step pedal foot lifter delay start time	120	0 — 2000	毫秒 Millisecond
P70	电机最大电流限制 Motor max electric current	350	50 — 600	
P71	最高速度锁定 Maximum speed lock	4200	200 — 6500	转 / 分钟 Round / Minute
P72	系统密码 System Password	2014	0000 — 9999	
P73	语音音量 Voice volume	25	0-30	

P74	语言选择 Language selection	0	0-1	0 中文 1 English
P75	开机语音 Boot voice	0	0-1	0 关闭 1 开启
P99	显示屏版本号 Display version	101		
P100	主控版本号 Controller version	0		
P101	步进方向 Step direction	1	0 — 1	
P102	步进原点偏移量 Step origin offset	32	0 — 360	度
P103	步进原点功率 Step origin power	10	0 — 12	
P104	步进剪线功率 Step thread cutting power	100		
P105	步进剪线角度 Step thread cutting angle	600	0 — 1500	
P106	步进进刀速度 Step forward knife speed	350	0 — 950	
P107	步进退刀速度 Step backward knife speed	150	0 — 950	
P108	步进进刀力度 Step forward knife power	5		
P109	步进退刀力度 Step backward knife power	2		
P110	步进抬压脚角度 Step motor presser foot lift angle	340	0 — 1500	
P111	步进抬压脚速度 Step motor presser foot lift speed	390	0 — 950	
P112	步进放压脚速度 Step motor release presser foot speed	300	0 — 950	
P113	步进抬压脚力度 Step motor presser foot lift power	6		
P114	步进放压脚力度 Step motor release presser foot power	2		

四：控制箱端口说明

The control box Port Description



端口序号 The port number	端口连接的器件名称 Port device name for the connection	端口说明 Port instruction		
①	LED 机头灯插孔 head LED socket		2:1	2:5V 1:GND
②	剪线功能端口 Trimming function port		2:1	2:剪线输出 trimming 1:34V
③	拨线功能端口 Air-suction function port		2:1	2:拨线输出 blowing 1:34V
④	抬压脚功能端口 Lifting presser foot function port		2:1	2:抬压脚输出 Presser foot lifting 1:34V
⑤	步进电机端口 Stepper motor port		4:1 3:2	4:Earth 1:V 3:W 2:U
			4:1 5:2 6:3	1:Z 2:QA 3:QB

五：错误代码解析： Error code analysis

显示的错误码 Display error code	错误码意思 Error code meaning	错误的产生 Various possible for the erro	解决错误 Solution
ER-01	找不到停针位 Not find needle position	1:手轮和电机靠的不够近 2: 手轮上磁钢脱落 3: 手轮磁铁极性装反 4: 九针端子头接触不良 5: 电机霍尔损坏，跟换电机 1: Hand wheel and motor 2: Hand wheel magnet off 3: Hand wheel magnet polarity reversal 4: Nine-pin terminal head Poor contact 5: Motor hall damaged, with the change	1: 检查电机信号线有无松动 2: 更换手轮 3: 更换电机 1: check whether the motor signal line is loose 2:replace the wheel 3: replace the motor

		motor	
ER-02	脚踏板信号错误 Foot controller signal error	1: 开机时没插调速器 2: 调速器插反 3: 调速器线断开 4: 调速器损坏 1: Not plugged foot controller into control box 2: foot controller inserted upside 3: foot control box line broken 4: foot controller damage	1: 检查调速器信号线 2: 更换调速器 3: 更换控制器 1: check the foot controller signal line 2: change the foot controller 3: replace the foot controller
ER-03	电机相位信号错误 Motor phase signal error	1: 九针插头接触不良 2: 电机安装时霍尔和转子存在大偏差 3: 电机霍尔坏 1: Nine-pin terminal plug Poor connect 2: Hall and rotor has large deviations when the motor is mounted 3: Motor hall damage	1: 打开电机上的橡皮盖通过孔看电机转子与定子是否在同一平面保障误差不超过1MM 2: 更换电机 3: 更换控制器 1: open the rubber cover on the motor through the hole to see whether the motor rotor and stator in the same surface to ensure the error is not more than 1MM 2: replace the motor 3: replace the control box
ER-04	电机堵转保护 Motor stall protection	1: 缝纫机过重或堵死 2: 电机过载 3: 电机 4 线驱动线没连接好或插反 1: Sewing machine overweight or blocked 2: Motor overload 3: 4-wire motor drive cable is not connected or inserted upside	1: 检查电机 4P 线 2: 检查缝纫机是否过重 3: 更换控制器 1: check motor 4P line 2: check whether the sewing machine is too heavy 3: replace the controller
ER-05	硬件过流保护 Hardware over current	1: 缝纫机过重或堵死 2: 电机过载 3: 电机相位信号线没连接好 4.功率管损坏 1: Sewing machine overweight or blocked 2: Motor overload 3: Motor phase signal line is not connected 4: Power tube damage	
ER-07	串口通讯超时 Serial communication timeout	1: 显示屏连接主板线连接不良 2: 主板芯片损坏 1: Display bad cable connection Motherboard 2: Motherboard chip damage	1: 检查显示屏与控制器连接线 2: 检查控制器是否还可运行，如不能运行就是控制器损坏 3: 检查机器旁是否有高频机器干扰 4: 更换显示屏 1: Check the connection line between the display screen and the control box. 2: check whether the controller run well, if not, controller damage 3: check whether there is a high frequency machine near the machine interference 4: change the display panel

ER-09	存储器不良 Poor memory	1:主板存储器损坏或不良 1: Motherboard memory corruption or bad	1: 控制器损坏 1: control box damage
ER-12	剪刀没有复位报警 Knife is not reset the alarm	1: 复位检测器坏了 2: 剪刀卡住没复位 1: Reset the detector is broken 2: knife stuck not reset	1: 检查霍尔是否损坏 2: 检查感应磁铁是否没有感应到 3: 检查感应磁铁磁极是否装反 3. 更换电控 1: check the hall is damage or not 2:check whether the induction magnet is detected or not 3: check induction magnet pole is installed in reverse or not 4. change the control box
ER-15	编码器故障 the motor board error		
ER-16	过压 Over load	1.电机驱动电源电压过高, 220V 电源电压超过限定值 (AC310V), 或负载惯性过大导致再生电压超过限定值(DC440V),或电压检测回路故障。(110V 控制系统电源电压超过限定值 (AC155V), 或负载惯性过大导致再生电压超过限定值(DC220V)). 1. The motor drive power supply voltage is too high, the 220V power supply voltage exceeds the limit value(AC310V), or the load inertia is too large to the regenerative voltage exceeds the limit value(DC440V), or the voltage detection circuit fails.Note:(110V control system power supply voltage exceeds limit value(AC155V), or load inertia is too large to regeneration voltage exceeds limit value(DC220V).	
ER-20	欠压故障 Under voltage error	1.电机驱动电源电压过低, 220V 电源电压低于限定值 (AC91V), 或电机驱动电源电压低于限定值 (DC130V),或电压检测回路故障。 注: (110V 电源电压低于限定值 (AC45.5V), 或电机驱动电源电压低于限定值 (DC65V)) 1. The motor drive power supply voltage is too low, the 220V power supply voltage is lower than the limit value(AC91V), or the motor drive power supply voltage is lower than the limit value(DC130V), or the voltage detection circuit fails. Note:(110 V power supply voltage is below the limit(AC45.5 V), or motor drive power supply voltage is below the limit(DC 65V))	



高林股份有限公司
KAULIN MFG. CO., LTD.

由於對產品的改良及更新，本產品使用說明書中與零件圖之產品及外觀的修改恕不事先通知！
The specification and/or the equipment described in the instruction book and parts list
are subject to change because of modification with out previous notice
HBL-19W12-2.APR.2026