


SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	988LQT	KA	△: Use for #4 □: Use for without ECB(ECM)(VTM)	1/1
				Date
				2024/09/26



SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	988LQT	KB	□: Use for without ECB(ECM)(VTM)	1/1
				Date
				2024/09/26



A

B


C

D

E



SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	988LQT	KC	△: Use for #4 □: Use for #5	1/1
				Date
				2024/09/26



SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	988LQT	KD	△: Use for #4 □: Use for #5	1/2
				Date
				2024/09/26


A

B


C

D


E




SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	988LQT	KD		2/2
				Date
				2024/09/26



GB055-KD208C-E



KD208C



(A)

DKUM0455E-3

DKUM0455E-2


DKUM0455E-4

DKUM0455E-6

DKUM0455E-7

GB055-DKUM0455E-E

SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	988LQT	KF		1/1
				Date
				2024/09/26



SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	988LQT	KG	Δ: Use for #4/ECB(ECM)(VTM) □: Use for #5/ECB(ECM)(VTM)	1/1
				Date
				2024/09/26

ΔKG211K
□KG262

SK250N

ΔSK437N

KG212

SK216

KG213K

ΔKG212-4

KG241

KG238

SK216

KG235

SK216

KG239

SK674N

□KG241-5

ΔKG223-4
□KG223-5

KG224

KG223

ΔKG225
□KG261

SK277N

ΔKG222
□KG245

KG223N

ΔKG221KN
□KG243K

SK230*2

KG41-A

SM340

KG27

KG29

SM280B

KG28

KG41-E

ΔSM251KP
□SM250

ΔKG92N
□KG267

SK216KP*2

KGXXXKN

KGXXXKN-E

KGXXXKN-A

DCXX

SK260*2

ΔGB055-E229U
□E218U

SK437*2

GB055-KG208U-A

□KG228-A

SK438*2

PP3053*3

KG208U

SK569

ΔKG201
□KG244

KG207

KG230

SK209*2


□KG229
□SK209*2

SK277*2

KG228

C KG03K KG06K KG68 KG05K KC229 KG264 KG07K*2 KG08 KG04K-Y1 KG04K-3	A KG03K KG06K KG265 KG05K KC229 KG264 KG07K*2 KG08 KG04K-2 KG04K-G
D KG03K KG06K KG68 KG05K KC229 KG264 KG07K*2 KG08 KG04K-R KG04K-1	B KG03K KG06K KG265 KG05K KC229 KG264 KG07K*2 KG08 KG04K-Y KG04K-3

SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	988LQT	KJ	△: Use for #4 □: Use for #5	1/1
				Date
				2024/09/26



SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	988LQT	KL	△: Use for #4 □: Use for #5	1/1
				Date
				2024/09/26

A

B

C


D

E


□KL209N-C1=□KL209-E+**P**+**S**

KM
SERIES


△KL205N-C1=△KL205N-E+**P**




SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	988LQT	KN	Use for #5 此頁僅限5線機型專用	1/1
				Date
				2024/09/26




SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	988LQT	KP		1/1
				Date
				2024/10/25




SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	988LQT	KQ	Δ: Use for #4/ECB(ECM)(VTM) □: Use for #5/ECB(ECM)(VTM)	1/1
				Date
				2024/09/26




<div>SIRUBA</div> <div>PARTS LIST</div>	Series	Parts Group	Subclass / Remark	Page
	988LQT	KR	△: Use for #4 □: Use for #5	1/1
				Date
				2024/09/26



<div> <div>SIRUBA</div> <div>PARTS LIST</div> </div>	Series	Parts Group	Subclass / Remark	Page
	988LQT	KS	△: Use for #4/ECB(ECM)(VTM)	1/1
			□: Use for #5/ECB(ECM)(VTM)	Date
			☆: Use for without ECB(ECM)(VTM)	2024/09/26



SIRUBA PARTS LIST	Series	Parts Group	Subclass / Remark	Page
	988LQT	KT		1/1
				Date
				2024/09/26



<div>SIRUBA</div> <div>PARTS LIST</div>	Series	Parts Group	Subclass / Remark	Page
	988LQT	KU	<div>△: Use for #4</div> <div>□: Use for #5</div>	1/1
				Date
				2024/09/26


A

B


C

D

E



<div>SIRUBA</div> <div>PARTS LIST</div>	Series	Parts Group	Subclass / Remark	Page
	988LQT	KX		1/1
				Date
				2024/09/26



<div>SIRUBA</div> <div>PARTS LIST</div>	Series	Parts Group	Subclass / Remark	Page
	988LQT	KZ		1/1
				Date
				2024/10/17

